

LIFT BAR PD

Bar to lift car frame for larger wheels with low profile tires.

INCLUDED:



Lift Bar (shown above)
4 M10x50 Hex Head Bolts
4 M10 Flat Washers

LIFT BAR INSTALLATION

STEP 1



Place RUN/TOW switch in TOW position. Chock wheels and lift cart. Place cart on jack stands as shown.

STEP 2



Remove the plate by removing the four factory bolts as shown.

STEP 3



Pry the leaf spring away from the cart to allow enough clearance for the lift bar.

STEP 4



Place lift block between leaf spring and frame.

STEP 5



Attach plate using supplied hardware.