

KEY

- | | |
|------------------------|--|
| 1. KEY SWITCH | 8. CIRCUIT BREAKER |
| 2. SPEED SWITCH | 9. DELAY TUBE |
| 3. MICRO SWITCH | 10. OUTER DIODE |
| 4. DIODE (2) | 11. INNER DIODE |
| 5. BATTERIES | 12. MOTOR |
| 6. SOLENOID SWITCH (3) | 13. RESISTOR |
| 7. SOLENOID SWITCH (2) | 14. PORTABLE CHARGER PLUG
or IN-CAR CHARGER |

COLOR CODE			
B	BLUE	Y	YELLOW
G	GREEN	W	WHITE
R	RED	OR	ORANGE
Unspecified - BLACK			




Figure 5-30. 1971 Model DE Wiring Diagram